

## How to Measure

### **HIGH SPORT BOOTS XP#1031**

- Small      9" to 10" circumference  
              14<sup>1</sup>/<sub>2</sub>" height
- Medium    10" to 11" circumference  
              15<sup>1</sup>/<sub>2</sub>" height
- Large      11" to 12" circumference  
              16" height

Measure circumference  
of fetlock

